

OEL Recommended Spare Parts List

C310/C330/C510/C530/ES5430



Revision 11

Rev	Unit Name	No.	Part No.	Part Name	Q' ty /Unit	Recommended Q' ty/Year			Remarks	Special	Del /Add	ks for environment
						per 500	per 1000	per 2000				
	Printer-NIP	1	44452301	Side-R Assy	1	1	2	4				
	Printer-NIP	2	44452401	Side-L Assy.	1	1	2	4				
	Printer-NIP	3	44452501	Base-Assy	1	1	2	4				
	Printer-NIP	4	44452601	Sensor Assy. -Regist	1	1	2	4				
	Printer-NIP	5	44452701	Front Assy. -Hop/Reg	1	1	2	4				
	Printer-NIP	6	44359201	Frame Assy. -MPT	1	1	2	4				
	Printer-NIP	7	44359601	Cover Assy. -MPT	1	1	2	4				
	Printer-NIP	8	44364101	Eject-Assy. -H	1	1	2	4	C510/C530			
	Printer-NIP	8	44364102	Eject-Assy. -L	1	1	2	4	C310/C330			
	Printer-NIP	9	44453501	Cover-Top-Assy-H	1	1	2	4	C510/C530			
	Printer-NIP	9	44453502	Cover-Top-Assy-L	1	1	2	4	C310/C330			
	Printer-NIP	11	44149701	PWR unit-ACDC Switch(200V)	1	2	4	8	Power-Unit (Low-Voltage)			
	Printer-NIP	12	44317201	LED Head Unit-51TRA	4	2	4	8	600dpi			
	Printer-NIP	13	44423902	Board-SOS-2 Maintenance spec. for OEL	1	2	4	8	Board PU/CU C510 OEL			
	Printer-NIP	13	44423912	Board-SOS-1 Maintenance spec. for OEL	1	2	4	8	Board PU/CU C310 OEL			
	Printer-NIP	13	44424002	Board-CLP-2 Maintenance spec. for OEL	1	2	4	8	Board PU/CU C530 OEL			
10	Printer-NIP	13	44424005	Board-CLP-2 Maintenance for ES5430 (OEL)	1	2	4	8	Board PU/CU ES5430 OEL			
	Printer-NIP	13	44424012	Board-CLP-1 Maintenance spec. for OEL	1	2	4	8	Board PU/CU C330 OEL			
	Printer-NIP	14	44370601	Plate-Board-B	1	1	2	4	C330/C530			
	Printer-NIP	14	44370602	Plate-Board-B-GDI	1	1	2	4	C310/C510			
	Printer-NIP	15	44455601	Cover-Board	1	1	2	4	C330/C530			
3	Printer-NIP	16	44508701	Plate-Assy-Board-C	1	1	2	4	C330/C530			
4	Printer-NIP	17	44453601	Cover-OP-Assy-PX750-H	1	1	2	4	C510/C530			
4	Printer-NIP	17	44453602	Cover-OP-Assy-PX750-L	1	1	2	4	C310/C330			
	Printer-NIP	18	44371101	Plate-Lockout	1	1	2	4				
	Printer-NIP	19	44371701	Cover-Side L	1	1	2	4				
	Printer-NIP	20	44371801	Cover-Side R	1	1	2	4				
	Printer-NIP	21	44371901	Cover-IF	1	1	2	4				
	Printer-NIP	24	44430501	CONN Cord-AMP16P-AMP16P	1	1	2	4	PWR unit-PU			
	Printer-NIP	25	44499201	Switch Assy. - InterLock	1	1	2	4				
	Printer-NIP	26	44360401	Plate-Front	1	1	2	4				
	Printer-NIP	27	44453701	Cover-Assy. -Rear	1	1	2	4				
	Printer-NIP	28	44474001	OR-Board-ORZ	1	2	4	8	Board-ORZ (High Voltage)			
	Printer-NIP	29	2381028P0069	SMCD-24-62BD (1. 0)	1	1	2	4	ORZ-PU			
	Printer-NIP	30	44369801	Gear-Liftup-C	1	1	2	4				
3	Printer-NIP	31	44378901	Spring-Fuse	2	1	2	4				
	Printer-NIP	32	44352601	Motor-DC (I)N	1	1	2	4	ID-Motor (Suction)			
	Printer-NIP	33	44430001	CONN Cord-JST9P-JST9P	1	1	2	4	ID Motor-PU			
	Printer-NIP	34	44370701	Plate-Beam-FU	1	1	2	4				
	Printer-NIP	35	44370801	Cover-Beam-FU	1	1	2	4				

Rev	Unit Name	No.	Part No.	Part Name	Q' ty /Unit	Recommended Q' ty/Year			Remarks	Special	Del /Add	ks for environment
						per 500	per 1000	per 2000				
	Printer-NIP	36	44370901	Plate-Rear	1	1	2	4				
	Printer-NIP	37	44371001	Cover-Code	1	1	2	4				
	Printer-NIP	38	44416301	Plate-Bottom	1	1	2	4				
	Printer-NIP	39	44353601	Motor-Fan(Blower)	1	1	2	4	ID-Fan			
	Printer-NIP	40	44371201	Frame-AC-Front	1	1	2	4				
2	Printer-NIP	41	44371302	Frame-Switch-Front	1	1	2	4				
	Printer-NIP	42	44371401	Frame-AC-Switch	1	1	2	4				
	Printer-NIP	43	44371501	Shaft-AC	1	1	2	4				
	Printer-NIP	44	44426401	ACINLET-SW-JST3P	1	1	2	4				
	Printer-NIP	47	44372001	Frame-MPT-Side	1	1	2	4				
	Printer-NIP	48	44453901	Plate-Assy-Board-A	1	1	2	4				
	Printer-NIP	49	44454001	FG-Assy-Fuser	1	1	2	4				
	Printer-NIP	50	44352501	Motor-FAN(60x25)	1	1	2	4	Front-Fan			
	Printer-NIP	51	44352502	Motor-FAN(60x25)	1	1	2	4	Rear-Fan(Exhaust)			
	Printer-NIP	52	44454101	Case-Cassette-Assy. -750	1	1	2	4				
	Printer-NIP	53	43922301	Roller-Assy-MPT	1	2	4	8				
	Printer-NIP	55	44416701	Gear-Reduct-Liftup-B	1	1	2	4				
5	Printer-NIP	56	43912906	Plate-Logo	1	1	2	4				
	Printer-NIP	57	43954009	Plate-name (C530)	1	1	2	4	C530dn			
	Printer-NIP	57	43954010	Plate-name (C510)	1	1	2	4	C510dn			
	Printer-NIP	57	43954011	Plate-name (C330)	1	1	2	4	C330dn			
	Printer-NIP	57	43954012	Plate-name (C310)	1	1	2	4	C310dn			
3	Printer-NIP	58	44430601	CONN Cord-JST3P-JST3P	1	1	2	4				
	Cover-OP-Assy-PX750	1	44504602	OR-Board -IBB-2	1	1	2	4	C510/C530			
3	Cover-OP-Assy-PX750	1	44504601	OR-Board -IBB	1	1	2	4	C310/C330			
8	Cover-OP-Assy-PX750	2	5150006P1602	SVC016002A-DYDC	1	1	2	4	Cyrillic			
	Cover-OP-Assy-PX750	3	2381028P0067	SMCD-12-217BD(1. 0)	1	1	2	4				
	Side-R Assy	1	43073101	Motor_Pulse_H0P	1	1	2	4	Belt-Motor			
	Side-R Assy	2	44349601	Motor-DC (F)	1	1	2	4	Fuser-Motor			
	Side-R Assy	3	44505801	OR-DOD	1	2	4	8	Board-DOD			
	Side-R Assy	4	44369901	Gear Assy. -CL35Z25	1	1	2	4	Up/Down-CL			
	Side-R Assy	5	44430102	CONN Cord-AMP4P-AMP4P	1	1	2	4	Belt Motor-PU			
	Side-R Assy	6	44430301	CONN Cord-JST8P-JST8P	1	1	2	4	Fuser Motor-PU			
2	Side-R Assy	7	42049901	Rubber-Foot	2	1	2	4				
3	Side-R Assy	8	2233013P0080	9715B-08Z02-G4C	1	1	2	4				
3	Side-R Assy	9	44430401	CONN Cord-AMP8P-AMP8P	1	1	2	4				
3	Side-R Assy	10	43073101	Motor_Pulse_H0P	1	1	2	4				
3	Side-R Assy	11	44430101	CONN Cord-AMP4P-AMP4P	1	1	2	4				
	Side-L Assy	1	2381028P0068	SMCD-16-527BD(1. 0)	1	1	2	4	ZHJ-PU			
	Side-L Assy	2	44429801	CONN Cord-AMP3P-AMP3P	1	1	2	4	ZHJ-Cass. SNS			
	Side-L Assy	3	44505601	OR-ZHJ	1	1	2	4	Board-ZHJ			
3	Side-L Assy	4	42049901	Rubber-Foot	2	1	2	4				
	Base-Assy	1	44354901	Gear-Assy. -CL25Z19	1	1	2	4	Duplex-CL			

Rev	Unit Name	No.	Part No.	Part Name	Q' ty /Unit	Recommended Q' ty/Year			Remarks	Special	De l /Ad d	ks for enviro nmen t
						per 500	per 1000	per 2000				
	Base-Assy	2	44429701	CONN Cord-AMP6P-AMP3P-AMP3P	1	1	2	4	PU-Dup. SNS			
	Sensor Assy. -Regist	1	42605201	Thermistor-Belt	1	1	2	4				
	Sensor Assy. -Regist	2	42058304	Solenoid	1	1	2	4	Shutter			
	Sensor Assy. -Regist	3	44430201	CONN Cord-AMP10P-AMP5PAMP5P	1	1	2	4	Sensor Assy-PU			
	Sensor Assy. -Regist	4	44356901	Guide-BF	1	1	2	4				
	Front Assy. -Hop/Reg	1	44261403	Clutch-3. 5	1	1	2	4	Hop-CL			
	Front Assy. -Hop/Reg	2	44261404	Clutch-4. 5	1	1	2	4	Reg-CL			
	Front Assy. -Hop/Reg	3	44261406	Clutch-3. 5	1	1	2	4	MTP-CL			
	Front Assy. -Hop/Reg	4	44429702	CONN Cord-AMP6P-AMP3P-AMP3P	1	1	2	4	PU-Hop. SNS			
	Front Assy. -Hop/Reg	5	44429601	CONN Cord-AMP7P-AMP3P-AMP3P	1	1	2	4	PU-Reg. SNS			
	Front Assy. -Hop/Reg	6	44483301	Roller-Assy-Hopping	1	1	2	4				
	Front Assy. -Hop/Reg	7	44483601	Roller-Assy-PickUp	1	1	2	4				
11	Front Assy. -Hop/Reg	8	44357901	Lever-Sensor-PaperEnd	1	1	2	4			A	
11	Front Assy. -Hop/Reg	9	44358001	Lever-Sensor-Hopping	1	1	2	4			A	
	Cover-Top-Assy	1	44498001	Cable-Head-Assy	1	1	2	4				
6	Cover-Top-Assy	2	44366601	Frame-Head-L	1	1	2	4				
6	Cover-Top-Assy	3	44366701	Frame-Head-R	1	1	2	4				
9	Cover-Top-Assy	4	44366901	Lever-Lock-Top	1	1	2	4				
11	Cover-Top-Assy	5	44426701	Plate-Head-FG	4	1	2	4			A	
11	Cover-Top-Assy	6	45589601	Plate-Head-FG-R	4	1	2	4			A	
	Cover-Assy. -Rear	1	44369501	Cover-Assy. -Stacker	1	1	2	4				
	Case-Cassette-Assy. -750	1	43963101	Spring-Retard	1	1	2	4				
	Case-Cassette-Assy. -750	2	44384701	Frame Assy. -Retard	1	1	2	4				
	FG-Assy-Fuser	1	44426501	CONN Cord-Drawer-JST4P	1	1	2	4	PU-Fuser			
	FG-Assy-Fuser	2	44430701	CONN Cord-JST8P-JST5PJST4P	1	1	2	4	PU-Fuser			
	Frame Assy. -MPT	1	43922402	Frame Assy. -Separator	1	2	4	8				
	Frame Assy. -MPT	2	44009301	Spring-Separator	1	1	2	4				
3	Frame Assy. -MPT	3	43922301	Roller-Assy-MPT	1	1	2	4				
7	Cover Assy. -MPT	1	42073501	Spring-Hopper	1	1	2	4				